



TRITON QUICK SET (T.Q.S)

TRITON QUICK SET (T.Q.S) Plugging Compound is a one part fast setting cementitious material developed to stem water flow but can be used as an all purpose instant setting repair mortar with a wide range of application.

A SIMPLE AND EASY TO USE VERSATILE MATERIAL, JUST ADD WATER.

INSTRUCTIONS FOR USE Mix up to 0.5kg of T.Q.S. at a time. Mix quickly with clean water to a mortar consistency within 30 seconds and apply immediately by trowel or gloved hand and apply constant even pressure (when plugging water flow – approx. 30-60 seconds) until set.

MIXING RATIO Mix 1 part water to 4 parts powder by volume or 1 part water to 5 parts powder by weight. (Dry powder weight approximately 1220gms per litre). The mixing ratio is not critical and has little effect on the setting time.

T.Q.S. Plugging Compound is non-toxic, contains no chloride and is free from synthetic resins or epoxides.



WARNING Use rubber gloves to protect from heat generated during the setting period.

STORAGE Store in dry conditions. Stored correctly, shelf life is 12 months.


CONSUMPTION 1.9kg/m² per mm thickness.

HEALTH & SAFETY T.Q.S. contains ordinary Portland cement and is alkaline when mixed. It is odourless, contains no organic solvent and is not flammable. In the case of eye or skin contact wash immediately with water or saline solution. Obtain medical attention if irritation persists. If ingested do not induce vomiting, wash mouth out with water, drink water and seek medical attention. Handle in accordance with good industrial hygiene and safety practices. Wear impermeable plastic or rubber gloves and enclosed goggles for eye protection at all times when handling alkaline materials. All chemical materials should be treated with care and kept away from children and animals at all times. For further information refer to our Health & Safety data sheets.

PLUGGING SEVERE LEAKS WITH TRITON QUICK SET




Chisel out defective area to a depth of approximately 50mm.
Wash out the cutting thoroughly with clean water to remove loose matter and soak the concrete.



Stem the flow of water by plugging the back of the cutting as illustrated with TRITON QUICK SET

Remove any loose material and ensure that the concrete is thoroughly soaked and will not absorb any more water.

Remove any surface ponding and treat the cavity with a brush on coat of TT55 as illustrated.



When the coating of TT55 has dried to a tacky consistency fill the cavity with sand/cement (3:1) mortar ensuring the same is compacted back to surface.

When the mortar has set, apply a coating of TT55 to the surface of the repaired area as shown.

For further information contact:

Triton Chemical Manufacturing Co.Ltd.

Unit 5, Lyndean Industrial Estate
129 Felixstowe Rd, Abbey Wood, London, SE2 9SG

Tel: 020 8 310-3929 or Fax: 020 8 312-0349

www.triton-chemicals.com

info@triton-chemicals.com

Ref: 03/00 DATA. T.Q.S